



## Application Of Spirit Wax On Timber Floors

### Step One (optional)

Apply two light even coats of Tung oil to bare timber floor with a lambs wool applicator. Allow to dry between coats, then buff with tan or red pads.

### Step Two

Dust mop, vacuum floor.

### Step Three

Apply 3 even coats of Safestep spirit based with lambs wool applicator or poly cotton mop buffing between coats to harden wax with either tan or red pad.

### Step Four

Buff Floor with either red or tan pads until desired appearance and hardness is reached.

***Note: Research Products Safe Step, when applied and maintained to manufactures specifications will meet and exceed Australian Standard AS/NZS 4586:1999 Slip resistance classification of new pedestrian surface materials.***

---

*High Technology Chemistry and Cleaning Systems for the Carpet Maintenance and Sanitation Industries.*

Wedina Holdings Pty Ltd A.B.N 65 002 373 319  
Head Office 104 Derby Street Silverwater 2128 Ph: (02) 9748 0321 Fax: (02) 96471020  
P.O Box 142 Artarmon NSW 1570  
E-mail: [sales@research-products.com.au](mailto:sales@research-products.com.au) Web: [www.research-products.com.au](http://www.research-products.com.au)